

DESCALER DW



ACID DESCALER FOR REMOVING CALCAREOUS RESIDUE

- Very effective and rapid
- Keeps dishwashers and washing machines perfectly efficient
- No foam formula

Phosphoric acid-based descaler for dishwashers and washing machines. Very quickly removes all calcareous residue.

HOW TO USE

MECHANICAL USE: dilute the product directly in the tank for dishwashers and act a wash cycle. **MANUAL USE:** let the components to descale soak. Leave to act and rinse.



DILUTION

10 - 30% (1 L - 3 L in 10 L of water).

TECHNICAL DATA

ASPECT: Clear liquid

COLOR: Pink

PERFUME: Technical

COV: 0,00%

PH	Active substance [%]	Density (g/ml)	Pressure (bar)	Viscosity (cP)	Total dry residue [%]
< 1,0	23 ± 1	1.126			

DESCALER DW

⚠ WARNINGS

May be corrosive to metals. Harmful if swallowed. Causes severe skin burns and eye damage. Wash hands thoroughly after handling. Wear eye protection. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician. Absorb spillage to prevent material damage. Contains PHOSPHORIC ACID.



DANGER



WARNING

📄 NOTES

Do not use on calcareous surfaces (marble etc.). Before use, please always refer to the Technical Data Sheet and the Safety Data Sheet, with the exposure scenario, of the product. Use the PPE specified in the Safety Data Sheet.

Sutter Professional cannot be considered liable for any damage due to improper product use.

Only for professional use. Safety data sheet available on request.

📦 PACKAGING

Code	Size	Quantity	Pallet
4979	Kg 5	4	9x4=36